

Quick guide to A.S. 30 motor programming

If more information is required, refer to the original instructions.

All sequences must be completed within 10 seconds

Assigning a remote to a motor

Method 1. Apply power to the motor(motor will jiggle), Press the learn button once, (motor will jiggle if successful) Only works for first remote assigned to motor.

Method 2. Tap red button on motor(motor will jiggle on release), Press the learn button once, (motor will jiggle if successful). This method will work anytime

Method 3. (must already have a remote assigned). Using first remote, Press the learn button 8 times, (motor will jiggle if successful). Then pick up second remote and Press the learn button once, (motor will jiggle if successful). The extra remote (or channel) is now assigned.

Changing the motors direction

Method 1. Press the learn button 6 times, then press down.

Method 2. Press and hold the red button on the motor for 3 seconds until motor jiggles

Enter step by step mode (moves in small increments)

Press the learn button once, then press up.

Exit step by step mode (moves normally)

Press the learn button once, then press down.

Set upper Limit

Press the learn button twice, then press up.

Set lower Limit

Press the learn button twice, then press down.

Set third Limit

Position blind, then touch the Stop button 4 times in succession.

Hold stop for 2 seconds to access third limit once set.

Delete upper Limit

Press the learn button 4 times, then press up.

Delete Lower Limit

Press the learn button 4 times, then press down.

Deleting remote controls

1. **Delete the entire remote control you are holding from the selected motor.** Press the learn button 7 times, then press up.
2. **Delete all channels from all remote controls from the selected motor.** Press the learn button 6 times, then press up.

